

2.4 Replacement Parts

2.4.1 Parts list

#	Item	Description	Qty
1	VA11FA06	ARCHED NARROW - METALLIC BLACK OVERLAP (To overlap thin facing materials like tile)	1
1	VA11FE06	STRAIGHT NARROW - METALLIC BLACK OVERLAP (To overlap thin facing materials like tile)	1
1	VA11TA	ARCHED MASONRY TRIM - METALLIC BLACK (Gives a flush finish with brick or stone)	1
1	VA11TR	STRAIGHT MASONRY TRIM - METALLIC BLACK (Gives a flush finish with brick or stone)	1
2	SE64628	REMOVABLE WOODEN HANDLE WITH ROD	1
3	SE63534	FIRESCREEN DOOR ASSEMBLY	1
4	30728	BLACK WOODEN DOOR HANDLE	2
5	SE63546	SLIDING GUIDE ASSEMBLY	2
6	PL63535	FIRESCREEN FRAME	1
7	PL63536	FIRESCREEN MECHE	1
8	PL63538	LEFT OR RIGHT FIRESCREEN RETAINER	2
9	PL63537	TOP OR BOTTOM FIRESCREEN RETAINER	2
10	30585	SLIDING DOOR GUIDE	4
11	SE63505	DOOR FRAME ASSEMBLY WITH GASKET	1
12	30173	STEEL RIVET	3
13	PL64542	GLASS DOOR LOCK	1
14	AC06815	BLACK GASKET AND SILICONE KIT 3/16" X 5'	1
15	SE63625	CERAMIC GLASS WITH GASKET 25 3/4" X 42 3/32"	1
16	AC06400	BLACK SELF-ADHESIVE GLASS GASKET KIT (6')	2
17	PL63568	GLASS RETAINER	4
18	30556	AIR CONTROL FINISHING TIP	1
19	PL63584	FRONT BOTTOM SPACER	2
20	PL63583	CENTRAL BOTTOM SPACER	1
21	PL63582	BACK BOTTOM SPACER	1
22	99999	BUILD TO ORDER	1
23	PL59765	4" AIR INTAKE ADAPTER	1
24	SE63555	AIR INTAKE HOUSING WITH MECHANISM	1
25	99999	BUILD TO ORDER	1
26	99999	BUILD TO ORDER	1
27	99999	BUILD TO ORDER	1
28	99999	BUILD TO ORDER	1
29	PL63580	CLEARANCES SPACER	4
30	99999	BUILD TO ORDER	1
31	21369	TOP INSULATION	2
32	PL63581	TOP SPACER	2
33	99999	BUILD TO ORDER	1

#	Article	Description article	Qté
34	21373	FRONT BOTTOM SMOKE FUNNEL INSULATION	1
35	21374	FRONT TOP SMOKE FUNNEL INSULATION	1
36	21372	FRONT CORNER SMOKE FUNNEL INSULATION	2
37	21371	SIDE SMOKE FUNNEL INSULATION	2
38	21368	REAR SMOKE FUNNEL INSULATION	1
39	21370	TOP SMOKE FUNNEL INSULATION	1
40	SE45543	FP11 INSTRUCTION MANUAL KIT	1
41	VA7070	CAST IRON ANDIRON	2
42	30109	BOLT HEX 1/4 - 20 X 1"	4
43	99999	BUILD TO ORDER	1
44	99999	BUILD TO ORDER	1
45	21379	REAR REFRACTORY INSULATION	9
46	VA11071BR	RUSTIC BRICKS SET	1
47	22199	LEFT BOTTOM REFRACTORY PANEL	1
48	22207	RIGHT BOTTOM REFRACTORY PANEL	1
49	22202	RIGHT BOTTOM REFRACTORY PANEL	1
50	22210	RIGHT TOP REFRACTORY PANEL	1
51	22200	REAR TOP REFRACTORY PANEL	1
52	22201	LEFT BOTTOM REFRACTORY PANEL	1
53	22208	REAR BOTTOM REFRACTORY PANEL	1
54	22209	REAR BOTTOM REFRACTORY PANEL	1
55	VA11071H	HERRINGBONE BRICK ASSEMBLY	1
56	22199	LEFT BOTTOM REFRACTORY PANEL	1
57	22207	RIGHT BOTTOM REFRACTORY PANEL	1
58	22205	RIGHT VERMICULITE PANEL	1
59	22206	REAR BOTTOM VERMICULITE PANEL	1
60	22203	REAR TOP VERMICULITE PANEL	1
61	22204	LEFT VERMICULITE PANEL	1
62	VA11071M	MODERN BRICK ASSEMBLY	1
63	22199	LEFT BOTTOM REFRACTORY PANEL	1
64	22207	RIGHT BOTTOM REFRACTORY PANEL	1
65	22213	RIGHT BOTTOM REFRACTORY PANEL	1
66	22218	SIDE CENTER REFRACTORY PANEL	2
67	22216	RIGHT TOP REFRACTORY PANEL	1
68	22211	REAR TOP REFRACTORY PANEL	1
69	22217	REAR CENTER REFRACTORY PANEL	1
70	22214	REAR BOTTOM REFRACTORY PANEL	1
71	22212	LEFT BOTTOM REFRACTORY PANEL	1
72	22215	REAR BOTTOM REFRACTORY PANEL	1

2.4.2 Exploded view for replacement parts

