

MAIN ASSEMBLY

Part #	Description				Not Shown in the drawing:
1) 942-681* 936-238	Right Side Cast Side Cast Gasket	22) 300-551	Door Latch		300-981* Cast Grill
2) 300-021	Flange Adaptor	23) 940-370/P 846-570	Door Glass Door Gasket Kit		948-137 Small Spring Handle Nickel
3) 942-691*	Ashlip	24) 936-238	Glass Retainer Glass Gasket (sold per ft.)		910-142 Fan Thermodisc
4) 300-006	Fan Clip	36) 033-953	Air Tube 3/4" (Qty:4)		910-138 2 Way Switch
6) 942-671* 936-238	Left Side Cast Side Cast Gasket	37) 020-957	Baffle (2/set)		910-140 3 Way Switch
8) 942-661*	Mantel Top	38) 820-482	Smoke Deflector		948-220 Hampton Logo Plate
15) 300-911*	Fan Assembly	40) 910-157/P	Fan Motor Only		910-678 120 Volt Power Cord
20) 300-571*	Door Assembly				300-513 Upper Door Hinge Assembly
21) 948-179 948-178	Wooden Handle Black Wooden Handle Dark Brown				948-155 Bottom Door Hinge Pin

* Last digit of part number represents color:
1 = Metallic Black, 5 = Timberline Brown,

