


Encore® Non-catalytic/Catalytic Wood Burning Stove Model 2040 Replacement Parts



Vermont Castings Group reserves the right to make changes in design, materials, specifications, prices and discontinue colors and products at any time, without notice.

Encore® Non-catalytic/Catalytic Wood Burning Stove Model 2040 Replacement Parts (continued)

Item	Description	Part Number	Item	Description	Part Number
1.	Brick Support Bracket	30005279	57.	Thermostat Handle	1600660
2.	Griddle Gasket	1203668	58.	Front Manifold	30002407
3.	Back	30005289	59.	Front	See Chart Pg. 36
4.	Refractory Rt End	30005497	60.	Flue Collar Gasket	30002422
5.	Refractory Lt End	30005498	61a.	Left Door	See Chart Pg. 36
6.	Refractory Support	30005233	61b.	Left Door	See Chart Pg. 36
7.	Gasket, Fiber, Refractory Support	30005237	62.	Door Hinge Strip	1308634
8.	Back Insulation Board	30005269	63.	Top	See Chart Pg. 36
9.	Outer Back	30005261	65.	Glass Clip Long	1601396
10.	Left Griddle Quadrant	30002399	66.	Front Door Handle & Shaft	30002717
11.	Right Griddle Quadrant	30002401	67a.	Right Door	See Chart Pg. 36
12.	Griddle	30002386	67b.	Right Door	See Chart Pg. 36
13.	HS Flue Collar	30005266	68.	Door Gasket	1203588
14.	Bracket Upper Side	30005267	69.	Glass Gasket	1203556
15.	Catalyst, Ceramic	30005353	70.	Left Door Glass	30005300
16.	Damper Ashdoor Gasket	1203588	71.	Right Door Glass	30005299
17.	Damper Ramp	1301811	72.	Door Hinge Pin	30002727
18.	Damper Housing	30005293	73.	Spacer (for Damper rod)	1201779
19.	Damper1	30006467	74.	Primary Air Valve Assy.	30005324
20.	Damper Tab1	1601488	74a.	Primary Air Frame	1307411
21.	Damper Rod1	1600851	74b.	Primary Air Rod	30005260
22.	Griddle Handle Assy	30002775	75.	Front Door Handle and Shaft	30002717
23.	Gasket, Fiber Back Refractory	30005270	76.	Thermostat Friction Spring	1201846
24.	Rheostat Bracket	30002863	77.	Thermostat Cable	5005471
25.	Refractory, Engine - E/D	30005202	78.	Thermostat Handle Bolt	1201243
26.	Damper Handle Screw	1201310	79.	Ash Pan Assy	5005746
27.	Damper Handle	1600664	80.	Flue Collar	See Chart Pg. 36
28.	Damper Handle w/Screw Assy	30002720	81.	Leg	See Chart Pg. 36
29.	Left Side	See Chart Pg. 36	82.	Hex Head Jam Nut	1203290
30.	Left Air Manifold	30002408	83.	Bottom Heat Shield	30002470
31.	Right Air Manifold	30005290	83a.	Bottom Heat Shield Rt Wing	30005030
32.	Right Side	See Chart Pg. 36	83b.	Bottom Heat Shield Lt Wing	30005031
33.	Thermostat Handle Base	30002716	84.	Grate Bottom	30005294
34.	Washer Damper Rod	1202560	85.	Thermostat Assy.	5005470
35.	Fireback Plate, S/S	30005217	86.	Washer	1202471
36.	Inner Bottom	30005291	87.	Handle Base Stub	30002714
37.	Ashdoor Hinge Upper	30002403	88.	Fallaway Handle Complete	30004175
38.	Door Handle Bracket	30002909	89.	Thermostat Handle Assembly	30007067
39.	Bottom Outer	30005292	90.	Primary Air Cover	30007069
40.	Ashlip	See Chart Pg. 36	91.	Primary Air Base	30007071
41.	Gasket, Fireback	30005209	92.	Temperature Probe	30007274
42.	Refractory, Fireback	30005302	93.	Bracket, Temperature Probe	30007278
43.	Retainer, Fireback Refractory	30005248			
44.	Refractory, Inner Cover	30005205			
45.	Andiron	30002397			
46.	Refractory, Access Cover	30007251			
47.	Leg Leveller	1201745			
48.	Ashdoor Handle Shaft	1600622			
49.	Pawl Assy	30005157			
50.	Ashdoor	30002392			
51.	Ashdoor Handle (Wood)	1600663			
52.	Ashdoor Hinge Rod	30002473			
53.	Cotter Pin, Ashdoor	30001749			
54.	Ashdoor Hinge Lower	30002404			
55.	Ashpan Bracket	1601039			
56.	Lower Side Bracket	30005268			