



MHSC reserves the right to make changes in design, materials, specifications, prices and discontinue colors and products at any time, without notice.

Defiant Woodburning Stove Model 1945

Item Description	Part Number
1. Secondary Air Cover Plate	1601492
2. Secondary Air Probe Assy	1601489
3. Secondary Air Link	1601486
4. Secondary Air Flap	1601490
5. Griddle Gasket	1203668

Item Description	Part Number
6. Back	30001581
7. Left Heat Deflector	1608629
8. Right Heat Deflector	1608630
9. Refractory Assy (Body only)	1602512
10. Catalytic Combustor (Boxed)	30001152

Defiant Woodburning Stove Model 1945 (continued)

Item Description	Part Number
11. Refractory Access Panel	1602511
12. Thermostat Friction Spring	1201846
13. Left Griddle Quadrant	1301807
14. Right Griddle Quadrant	1301832
15. Griddle	1301641
16. Griddle Handle	1600657
17. Griddle Handle Spacer	1600070
18. Griddle Handle Bolt	1200907
19. Upper Fireback Assy	5000030
20. Damper Ramp ¹	1300643
21. Upper Firebrick ¹	1300633
22. Damper ¹	1300634
23. Damper Tab ¹	1601488
24. Damper Rod ¹	1600065
25. Griddle Handle Bushing	1201895
26. Throat Baffle	1300635
27. Lower Fireback	1300638
28. Upper Fireback Bolt	1201374
29. Damper Handle Screw	1201310
30. Damper Handle	1600664
31. Damper Handle Base Assy	30002720
32. Left Side	See Chart Pg. 38
33. Left Air Plate (Inner Side)	1300637
34. Right Air Plate (Inner Side)	1300636
35. Right Side	See Chart Pg. 38
36. Thermostat Handle Base Assy	30002716
37. Thermostat Assy	5005470
38. Grate	1300639
39. Primary Air Cover Plate	1300622
40. Top Ashdoor Hinge Support	30001689
41. Door Handle Holder	1600600
42. Bottom	30001577
43. Ashlip	See Chart Pg. 38
44. Left Side Wedge	1300628
45. Right Side Wedge	1300644
46. Firebrick (1¼" x 4½" x 9")	1601103
47. Firebrick Retainer	1600066
48. Andiron	1300646
49. Andiron Shelf	1300640
50. Leg Leveller	1201745
51. Ashdoor Handle Shaft	1600622
52. Door Latch Assy	5004025
53. Ashdoor	1300619
54. Ashdoor Handle (Wood)	1600663
55. Ashdoor Hinge Rod	30004028
56. Cotter Pin, Ashdoor	30001749
57. Ashdoor Bottom Hinge Support	1300642
58. Ashpan Bracket	30001908
59. Primary Air Valve Assy	5000024
60. Primary Air Frame ³	1307411
61. Primary Air Rod ³	1600058
62. Primary Air Valve ³	1307412

Item Description	Part Number
63. Thermostat Handle (Wood)	1600660
64. Airwash Manifold	1300627
65. Front	See Chart Pg. 38
66. Thermostat Cable	5005471
67. Left Door	See Chart Pg. 38
68. Door Hinge Strip	1300645
69. Top	See Chart Pg. 38
70. Glass Clip	30001715
71. Glass Clip (Right Door only)	30001716
72. Front Door Handle & Shaft	30002717
73. Right Door	See Chart Pg. 38
74. Door Gasket	1203588
75. Gasket, Fiberglas 3/16 4nd, Blk	1203556
76. Left Door Glass ²	1600064
77. Right Door Glass ²	1600062
78. Lower Door Hinge Pin	30002727
79. Spacer (for Damper Rod)	1201779
80. Upper Door Hinge Pin	30002727
81. Handle Base Stub	30002714
82. Wood Handle	1600664
83. Handle Bolt	1201310
84. Thermostat Handle Bolt	1201243
85. Ash Pan Assy ⁵	30001690
86. Flat Washer	1202475
87. Flue Collar	See Chart Pg. 38
88. Leg	See Chart Pg. 38
89. Finish Bag	30001695
90. Washer, 1/4 Flat	1202471
91. Hex Head Jam Nut	1203290
92. Bottom Heat Shield (not shown)	1400008
93. Ashdoor Heat Shield (not shown)	1401911
94. HS Spacer 1.25" (not shown)	1601755
95. Control Spacer (not shown)	1201781

NOTES:

In this diagram and throughout this manual, 'left' and 'right' mean as you face the stove.

When ordering parts, be sure to mention the stove's model number. When ordering external parts, be sure to specify color.

1. Included in Item #19, #5000030 Upper Fireback Assy.

2. Not interchangeable, due to a heat-reflective coating on the room side of the glass.

3. Included in Item #59, 5000024 Primary Air Assy.

The hardware in the Defiant is in standard sizes; most bolts are 1/4" diameter by 20 threads per inch. Any hardware store can supply replacement hardware if you specify bolt diameter, number of threads per inch and length.