


EXPLODED VIEW

ITEM NO.'S

- 1. Leg
- 2. Base
- 3. Outer Back Panel
- 4. Left Hand Side Panel
- 5. Right Hand Side Panel
- 6. Front

- 28. Fire Fence
- 29. Fire Fence Spike
- 30. Heat Exchanger
- 31. Hob
- 32. Flue Spigot
- 33. Hob Extension - (Horizontal)
- 34. Hob Extension - (Vertical)
- 34A. Knob to Shutter
- 35. Side Shelf (Optional)
- 36. Side Shelf Bracket (Optional)
- 37. Front ADS Assembly
- 38. Top Air Duct Assembly
- 40. Side Filler Plates
- 41. Mesh Cover for Ceramic Blanket
- 42. Lower Air Box Assembly
- 43. Left Side Wall Brick
- 44. Floor Bricks
- 45. Side Door Insulation Sheet
- 46. Ceramic Blanket
- 47. Heatshield



- 48. Filler Plate
- 49. Window Glass
- 50. Window Clip
- 51. Rope Channel
- 52. Ash Pan
- 53. Ash Pan Lifting Tool
- 54. Door Latch
- 55. Door Catch
- 56. Tension Pin
- 57. Ash Pit Door Handle
- 58. Ash Door Latch
- 59. Door Latch
- 60. Hinge
- 61. Door Hinge
- 62. Door Handle
- 62A. Side Door Handle
- 63. Door Handle Axle

- 64. Spacer to Door Handle
- 66. Spacer to Door Handle Axle
- 67. Door Stop
- 69. Damper Handle
- 70. Primary Air Flap Axle
- 71. Primary Air Control Link Rod
- 72. Primary Air Control Lever
- 73. Primary Air Control Lever Spacer (Small)
- 75. Ashtray Bracket
- 76. Ashtray Strap
- 78. Ash Side Shaft (Optional)
- 99. Flue Spigot Shield (Optional)
- 101. Ducting for Optional Fan
- 102. Optional Fan Assembly
- 103. Hob Bracket (Optional)

- 7. Front Door
- 8. Door Grille
- 9. Side Door
- 10. Side Door Protection Plate
- 11. Ash Pit Door
- 12. Front Ash Tray
- 13. Side Ash Tray
- 14. Combustion Chamber Base Plate
- 15. Fire Bed Grate
- 16. Guide to Ashpit Sliding Door
- 16A. Ashpit Sliding Door
- 17. Inner Back Panel
- 18. Inner Back Panel RH Filler Casting
- 19. Inner Back Panel LH Filler Casting
- 21. RH Front Air Duct (Ramp)
- 22. LH Front Air Duct (Ramp)
- 23. Outer Air Spigot
- 24. Inner Air Spigot
- 25. Damper Spacer
- 26. Damper Flap (ULC Stoves)
- 27. Damper Flap (UL Stoves)