

Replacement Parts List

Common To Traditions, Profiles 20 & 30

#11756300	Auger
#12051263	Ultragrate Replacement
#12050011	Combustion Blower
#12146109	Convection, Hardwasher, Blower
#12046300	Auger Motor
#12050815	Wiring Harness
#16050001	Pressure Switch
#12058820	Power Cord
#12147705	Snapswitch, 250 DG (L250-30F, 60T21)
#61050003	Auger End Plate Gasket, 5pc.
#61057203	Convection fan Gasket, 5pc.
#61050005	Combustion Fan Gasket, 5pc.
#12041300	Auger Collar & Screw Set (3 pieces)
#12050111	Combustion Fan (Motor Only) Kit
#12140213	Igniter Replacement
#16050205	Thermostat
#61050041	Gasket, Combustion Blower (Motor Only) 5pc.
#12050093	Quick Disconnect 3" Vent Side
#12055500	Grate Scraper
#15051547	Gasket, Door, 3/4" Rope, (8 ft.)

Traditions (Freestanding)

#11750015	Firebrick set
#11750003	Door Handle Assembly, Kit
#16055150	Control Board
#19050196	Photoeye Assembly
#20959999	Door, Glass
#61057208	Glass Gasket (4')
#15051547	Gasket, Door, 3/4" Rope, (8 ft.)
#11750011	Brick Clips (2 clips)
#20950100	Rear Panel Assembly
#20950205	Hopper Lid Assembly, Kit
#20950110	Gasket, Quick Disconnect
#17150029	Damper Rod Assembly, Kit
#20950087	Auger, Flange
#20950091	Ashpan Assembly
#20953006	Trivet, Black
#20950014	Heat Exchange Baffle
#20950068	Photoeye Mount
#20953013	Cast Top, Black Enamel
#20953053	Cast Top, Green Enamel
#20953083	Cast Top, Sand Enamel
#20953003	Cast Top, Black Painted
#20953012	Cast Door Frame, Black Enamel
#20953052	Cast Door Frame, Green Enamel
#20953082	Cast Door Frame, Sand Enamel
#20953002	Cast Door Frame, Black Painted
#20950153	Log Set
#20951000	Trivet, Gold Plated
#20751075	Leveler Legs (2pc.)
#26021	Touch Up Paint, Green (for enamel)
#26022	Touch Up Paint, Black (for enamel)
#26023	Touch Up Paint, Sand (for enamel)

Profile 30 (Freestanding-FS, Insert-IN, Common-C)

#14750015	Firebrick Set-C
#14750111	Firebox Door Assembly
#17150095	Door Handle-C
#16052112	Control Board-C
#19050196	Photoeye Assembly
#61057208	Gasket, Glass (4ft.)-C
#14750021	Hinge Bracket-C
#11750011	Brick Clips-C
#17250241	Auger Flange-C
#12146402	Replacement Glass-C
#15051547	Gasket, Door, 3/4" Rope, (8 ft.)
#14750070	Side Panel, LHS-FS
#14750075	Side Panel, RHS-FS
#14750060	Top Panel-FS
#14750150	Rear Panel-FS
#14750340	Side Panel, LHS-IN
#14750345	Side Panel, RHS-IN
#14750300	Top Panel-IN
#14750057	Trim Set, Nickel-C
#14750056	Trim Set, Gold-C
#61050016	Gasket, Quick Disconnect 5pc.-C
#14756100	Shroud, Small-IN
#14757100	Shroud, Medium-IN
#14758100	Shroud, Large-IN
#14750201	Trim, Large Shroud, Gold-IN
#14750101	Trim, Medium Shroud, Gold-IN
#19350008	Trim, Small Shroud, Gold-IN

Profile 20 (Freestanding)

#14650001	Firebrick Set
#14650006	Firebox Door Assembly
#17150095	Door Handle
#16053941	Control Board
#19050196	Photoeye Assembly
#61057202	Gasket, Glass (10ft.)
#14650047	Hinge Bracket
#13640028	Brick Clips
#17250241	Auger Flange
#12050021	Replacement Glass, Side (1pc.)
#12050020	Replacement Glass, Front
#15051547	Gasket, Door, 3/4" Rope, (8 ft.)
#14650003	Side Panel, LHS
#14650004	Side Panel, RHS
#14650001	Top Panel
#14650048	Rear Panel
#14650057	Trim Set, Nickel
#14650056	Trim Set, Gold
#61050016	Gasket, Quick Disconnect 5pc.